# HD tachograph

This product uses high-performance chips to provide high-definition video and seamless dynamic images. Support 1080PFHD and 720P video recording. Please read this manual carefully before use and keep it properly. We hope this product can meet your needs and serve you for a long time!

**Description of appearance and key functions**




1. Mode key/menu
2. Up key
3. Flip down key
4. Power key/OK confirmation key
5. USB power
6. AV-IN interface
7. Video indicator
8. 3.16 inch display
9. TF card slot
10. Camera
11. Horn
12. Reset keyhole

**1. Power key/OK confirmation key**

Function 1: On/Off function

In the shutdown state, short press the [Power Key] to turn on the power of the machine, and the machine automatically starts to work. In the power on state, long press the [Power Key] for 3 seconds to automatically save the video files and user settings and turn off the computer.

**OK confirmation key**

Function 1: In the main interface or video recording interface, press [Power Key] briefly to turn on/off video recording.

Function 2: In the video playback interface, short press [Power Key] to play/pause the file

Function 3: In the setting interface, briefly press [Power Key] to save the setting task

**2. Mode key/menu**

In standby mode, press the mode key briefly to enter the main interface; Long press the mode key to enter the setting menu;

**3. Turn up key**

In standby mode and menu mode, press the scroll up key briefly to scroll up;

In the main interface mode, briefly press the up key to turn on or off the recording volume;

In the video playback mode, press the scroll up key briefly to reduce the playback volume.

**4. Turn down key**

In standby mode and menu mode, press the flip key briefly to scroll down for setting;

In the main interface mode, press the flip key briefly to switch the front and rear view picture in picture interface;

In the video playback mode, press the scroll up key briefly to increase the playback volume.

## 2、 Installation Guide

1. Turn off the car engine.
2. Insert the TF card into the recorder card slot.

[Note] Please use a high-speed TF card (above Class6) with a capacity of no less than 4GB. The TF card supports a maximum of 32GB.

3. Fix the recorder on the original rearview mirror of the car.

4. Insert the car charger into the cigarette lighter.

5. Connect the USB interface of the recorder to the vehicle charger with the charging extension cable.

[Note] During wiring, the charging extension line can be laid along the edge of the windshield.

6. Install the rear camera at the rear of the vehicle, and pay attention to the direction during installation. The wiring can be laid along the vehicle roof. After installation, connect the rear plug to the recorder AV-IN.

7. Adjust the lens position to ensure that the lens is level with the ground.

8. Start the engine and check whether the machine is installed correctly.

[Note] When the machine is installed correctly, the system operation indicator is on; The machine starts to enter the recording state, and the recording indicator flashes. Please check whether the picture on the display screen is normal. If the picture is inverted, please contact us in time.

**3、Function introduction**

**1. Use the driving video function**

Start the car engine, the recorder will start automatically and start the video recording function. Click "DASH CAM" on the main interface to enter the video recording interface, and click the video icon " ◯ " to start or close the video recording function; Click the video recording button on the main interface to enable or disable the video recording function. When the icon display solid is red and flashing. When the car engine is turned off, the recorder automatically saves the video content and shuts down. The video recorded is saved in segments on the TF card. When the TF card is full, the recorder will overwrite the video recorded earlier.

[Note] a The recorded time period can be set to 1/2/3/5 in the menu. If any of the four levels of "1/2/3/5" minutes is selected, when the TF card is full, the recorder will overwrite the previously recorded image;

b. The video files and photo files of the front and rear cameras are saved in

the "DCIMA folder" and "DCIMB folder" respectively under the "DCIM" directory in the TF card

**2. Use the photographing function**

Click "Take a picture" on the main interface to enter the photographing mode, and click the icon of "Take a picture" to take a picture; To return to the main interface, click the Back button at the bottom right of the screen " " return to the main interface.

**3. Video playback**

Click "Video Playback" on the main interface to enter the playback mode, and click " " The current file can be locked. Click " " To unlock the current file, click " " " " You can page up and down the file and click the play key icon " ▷ " Perform video playback. Click the icon when the video is playing " " The video can be rewinded by clicking the icon " " The video can be fast forwarded. Click the Back button icon at the bottom right of the screen " " Return to the main interface.

**4. One key locking function**

In the video recording, click the lock flag " " Lock the current video, locked files, and the lock icon is " ", click " " Unlock the current file. The locked file will not be overwritten.

**5. One button mute function**

Click the microphone icon in the main interface or video mode " " Turn recording on or off.

[Prompt] The settings will be saved automatically, and there is no need to set the mute function after restart.

**6. Camera interface switching function**

In the video interface. Click the interface conversion icon " " Pull the interface screen forward/backward and switch between picture in picture.

**7. Time/date setting**

In the menu bar, select the "Time/Date" option in "General Settings" to set the time/date.

[Note] In order to effectively record the date and time of obtaining evidence for driving safety accidents, please set the correct time before using this machine.

**8. Movement detection function**

Click "Function Setting" in the main interface to enter the function setting interface, click video recording setting and then click motion detection to turn on/off the motion detection function. When the current camera senses that there are moving objects in the surrounding area, the machine automatically enters the camera state. The system stops recording 10 seconds after the front camera does not detect moving objects

[Prompt] If you need to use the movement detection function for a long time, please keep the machine powered on for a long time.

[Note] Please enter the settings and exit the motion detection when the recording is stopped.

**9. Collision sensing function (optional)**

The machine has a built-in collision sensor (G-sensor). Click "Function Setting" on the main interface to enter the function setting interface. Click the video recording setting, and then click the scroll down key to find "Gravity Sensing". Click the gravity sensing to set the collision sensing function. The machine will automatically lock the current video if it vibrates (such as collision) during the recording process.

[Prompt] The G-sensor supports sensitivity adjustment: off/high/medium/low, and can change the settings in the gravity sensor settings according to actual needs.

**10. Parking monitoring function (optional)**

Click the function setting in the main interface to enter the function setting interface, click the video recording setting, and then find the parking monitoring function. When the parking monitoring function is turned on, if the car has a slight vibration in the shutdown state, the recorder will automatically start recording and lock. This video is locked and will not be overwritten. After 17 seconds of recording, the machine will automatically shut down.

**11. Reversing visibility**

First of all, connect the car charger to the recorder, pull the camera plug back to connect to the AV-IN socket, and pull the black red wire on the camera to connect the reversing lamp. The car charging machine will automatically start the recording state. If there is a reverse in any state, the reverse image will be displayed. The machine will automatically return to the video recording mode after the end of reverse viewing.

## Version 1080-YJ3008-LX7701


Auto power off
Date/Time
Auto power off
Screen saver
Buttons sound
Language
Off
1 minute
3 minutes
MODE
OK


Buttons sound
Date/Time
Auto power off
Screen saver
Buttons sound
Language
Off
On
MODE
OK

Date/Time
Date/Time
Auto power off
Screen saver
Buttons sound
Language
05 / 02 / 2025
11 : 41 : 22
MM / DD / YY
MODE
OK

Language
Date/Time
Auto power off
Screen saver
Buttons sound
Language
English
Tiếng Việt
简体中文
日本語
Français
MODE
OK

Screen saver
Date/Time
Auto power off
Screen saver
Buttons sound
Language
Off
1 minute
3 minutes
5 minutes
MODE
OK


Park mode
Date stamp
G-sensor
Park mode
Off
26
46
86
MODE
OK

G-sensor
Date stamp
G-sensor
Park mode
Off
2G
4G
8G
MODE
OK

Version
Frequency
Format
1084-YJ3008-LX7701
Default settings
Version
MODE
OK

01:50:00
1296P

HD 1080P

TF
MIC
AV
USB